

# MiCAT

Mitutoyo Intelligent Computer Aided Technology

the standard in world  
metrology software

**FORM**

No. 99MBB500A

## RA-10/120 USB Communication

# User's Manual

Read this User's Manual thoroughly  
before operating the instrument. After reading,  
retain it close at hand for future reference.

**Mitutoyo**



# CONVENTIONS USED IN THIS MANUAL

## Safety Precautions

To ensure that instruments are operated correctly and safely, Mitutoyo manuals use various safety symbols (Signal Words and Safety Alert Symbols) to identify and warn against hazards and potential accidents.

The following signs indicate general warnings:



**DANGER**

Indicates an imminently hazardous situation which, if not avoided, will result in serious injury or death.



**WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in serious injury or death.



**CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.

The following signs indicate specific warnings or prohibited actions, or indicate a mandatory action:



Alerts the user to a specific hazardous situation. The given example means "Caution, risk of electric shock".



Prohibits a specific action. The given example means "Do not disassemble".



Specifies a required action. The given example means "Ground".

# CONVENTIONS USED IN THIS MANUAL

## Types of Notes

The following types of notes are used in this manual to help the operator obtain reliable measurement data through correct instrument operation.

- 
- IMPORTANT**
- An important note provides information essential to the completion of a task. You cannot disregard this note to complete the task.
  - An important note is a type of precaution, which if neglected could result in a loss of data, decreased accuracy or instrument malfunction/failure.
- 

- 
- NOTE**
- A note emphasizes or supplements important points of the main text. It also supplies information about specific situations (e.g., memory limitations, equipment configurations, or details that apply to specific versions of a program).
- 

- 
- TIP**
- A tip is a type of note that helps the user apply the techniques and procedures described in the text to his or her specific needs.
- It also provides reference information associated with the topic being discussed.
- 

Mitutoyo assumes no liability to any party for any loss or damage, direct or indirect, caused by use of this instrument not conforming to this manual.

Information in this document is subject to change without notice.

**© 2009 Mitutoyo Corporation. All rights reserved.**

## **Warranty**

---

In the event that the Mitutoyo data processing unit should prove defective in workmanship or material, within one year from the date of original purchase for use, it will be repaired or replaced, at our option, free of charge upon its prepaid return to us.

If the unit fails or is damaged for any of the following reasons, it will be subject to a repair charge, even if it is still under warranty.

- 1 Failure or damage owing to inappropriate handling or unauthorized modification.
- 2 Failure or damage owing to transport, dropping, or relocation of the instrument after purchase.
- 3 Failure or damage owing to fire, salt, gas, abnormal voltage, or natural disaster.

This warranty is effective only where the instrument is properly installed and operated in conformance with the instructions in this manual.

## **Export Control Compliance**

---

This Product falls into the Catch-All-Controlled Goods or Program under the Category 16 of the Separate Table 1 of the Export Trade Control Order or the Category 16 of the Separate Table of the Foreign Exchange Control Order, based on the Foreign Exchange and Foreign Trade Law of Japan.

Further, this User's Manual also falls into the Catch-All-Controlled Technology for use of the Catch-All-Controlled Goods or Program, under the Category 16 of the Separate Table of the Foreign Exchange Control Order.

If you intend re-exporting or re-providing the product or technology to any party other than yourself, please consult with Mitutoyo prior to such re-exporting or re-providing.

## **Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)**

---



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. To reduce the environmental impact of WEEE (Waste Electrical and Electronic Equipment) and minimize the volume of WEEE entering landfills, please reuse and recycle.

For further information, please contact your local dealer or distributors.

---

# Contents

---

<b>CONVENTIONS USED IN THIS MANUAL.....</b>	<b>i</b>
<b>Warranty.....</b>	<b>iii</b>
<b>Export Control Compliance.....</b>	<b>iii</b>
<b>isposal of Old Electrical &amp; Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems).....</b>	<b>iii</b>
<b>Contents.....</b>	<b>iv</b>
<b>1 RA-10/120 USB Communication Install.....</b>	<b>1-1</b>
<b>2 RA-10/120 USB Communication Starting.....</b>	<b>2-1</b>
<b>2.1 Before starting .....</b>	<b>2-1</b>
<b>2.2 Method of starting .....</b>	<b>2-3</b>
<b>3 RA-10/120 Summary of USB Communication .....</b>	<b>3-1</b>
<b>3.1 Overall view.....</b>	<b>3-1</b>
<b>3.2 Operation procedure .....</b>	<b>3-3</b>
<b>3.3 Generating an inspection certificate .....</b>	<b>3-4</b>
<b>4 RA-10/120 Method of USB Communication Usage .....</b>	<b>4-1</b>
<b>4.1 Reading.....</b>	<b>4-1</b>
<b>4.2 Print.....</b>	<b>4-2</b>
<b>4.3 Print preview .....</b>	<b>4-3</b>
<b>4.4 Export .....</b>	<b>4-3</b>
<b>4.5 Language setting.....</b>	<b>4-5</b>
<b>4.6 Comment settings .....</b>	<b>4-6</b>
<b>4.7 Print settings.....</b>	<b>4-7</b>
<b>4.8 Paper selection .....</b>	<b>4-7</b>
<b>4.9 Figure .....</b>	<b>4-7</b>
<b>4.10 Quit.....</b>	<b>4-7</b>
<b>5 USB Communication Performance Environment.....</b>	<b>5-1</b>

# 1


## RA-10/120 USB Communication Install

This chapter explains regarding “USB Communication Install” procedure.


It is necessary to install a RA-10/120 communication driver to use “USB Communication”.

Set the CD-ROM including the application into the CD-ROM drive. Execute [Driver\_Setup.exe] in the driver folder in the CD-ROM. Execute install with following the guidance.

1. After executing [Driver\_Setup.exe], the below message appears occasionally according to user account control. If it appears, select [Allow] and go on to the next operation.



2. Then a confirmation message of [Device Driver Installation Wizard] appears.  
Click [NEXT], and then the installation will start.



Here, the message on the right appears occasionally. If it appears, click [Install this driver software anyway] at the bottom.



3. When the message of [Completing the Device Driver Installation Wizard] appears, the installation of USB driver has been completed. Click [Finish].



# 2

## RA-10/120 USB Communication Starting


This chapter explains regarding the method of starting USB communication.

### 2.1 Before starting

- (1) Excel manufactured by Microsoft (from U.S.A) has to be installed to start the program. Regarding the performance environment, refer to [Chapter 5].
- (2) Connect a USB cable.  
USB cable (part №12AAD510) is not included in this product. It is necessary to arrange separately. Please prepare the type-AB if you get it on the market.

### 2.2 Method of starting

- (1) Copy all the Application folders in the CD-ROM to arbitrary place on the hard disc.
- (2) Double-click [RA-120COM\_USB.exe] in the application folder



---

MEMO


# 3

## RA-10/120 Summary of USB Communication

This chapter explains regarding the summary of USB Communication.

It is available to create a “simple inspection certificate” with “RA-10/120 USB Communication” based on the calculation result of RA-10/120.


### 3.1 Overall view



- ① Condition list : Display the condition of the data taken from RA-10/120.
- ② Result list : Display the result of the data taken from RA-10/120.
- ③ Figure window : Display the figure of the data taken from RA-10/120.
- ④ Operation button : Reading the data from RA-10/120, creation of a simple inspection certificate..  
Regarding the details, refer to [Chapter 4]


## 3.2 Operation procedure

This section explains regarding the procedure in the case of using “RA-10/120 USB Communication”. Operation method for the main function is as below.



### 3.3 Generating an inspection certificate

- (1) This program can generate a simplified inspection certificate based on calculation results and evaluation profile data.
- (2) Click "RA-120COM\_USB.exe" to start "RA-10/120 USB Communication".
- (3) Select [Automatic Print] from the Print Method box.
- (4) Select either A4-size or letter-size print sheet.
- (5) Following steps can be performed automatically by clicking [Calc. Result]:  
Loads data from the control unit → Creates an inspection certificate → Prints an inspection certificate
- (7) The evaluation conditions and calculation results of loaded data can be also confirmed on the screen of RA-10/120 USB Communication.



---

MEMO

# 4

## RA-10/120 Method of USB Communication Usage

This chapter explains regarding the method of USB Communication usage.

### 4.1 Reading



Press the [Read] button to read the measurement data. The taken data are displayed on [Condition list], [Result list], and [Figure window].

The contents displayed on each list are as below.

#### (1) Condition list

	Item	Contents	
1	Filter	NON, 2CR50, 2CR75, 2CRPC50, 2CRPC75, Gaussian (*1)	Any one
2	CUT-OFF	15pc/r,50pc/r,150pc/r,500pc/r,15-150pc/r,15-50pc/r,,50-500pc/r ,NON (*1)	Any one
3	Record Mag.	x5,x10,x20,x50,x100,x200,x500,x1k,x2k,x5k,x10k	Any one
4	Ref-Circle	LSC,LSCI,MZC,MZCI,MIC,MICI,MCC,MCCI,LS,LSPL,MZ,MZP L,NON	Any one
5	Tolerance	○.○○○○ [Unit]	
6	ISO2011(JIS)	ON,OFF	Any one
7	Elements	○	

#### (2) Result list

	Item	Contents	
1	Analysis item	Roundness,RONt,Coaxiality ,Concentricity, Runout(RDL) ,Runout(AXL) , Squareness(AXS), Squareness(PLN),Thickness-DV, Flatness,FLTt,Parallelism, Parallel(Runout), Cylindricity, Simple Cylind, Mean Cylind (*1)	Any one
2	Result	OK,NG	Any one
3	Relevant analysis result	(*2)	

(\* 1) If the analysis condition does not comply with the standards, each items are followed by \*.  
(Ex. 2CR50 \*)

---

(\*2) It depends on the analysis item.

	Item	Contents (Some are not printed out depends on RA-120 settings.)
1	Roundness	P,V,MLA,PC,DX,DY,DL,DA
2	RONt	RONp,RONv,RONq,PC,DX,DY,DL,DA
3	Coaxiality	DX,DY,DL,DA
4	Concentricity	DX,DY,DL,DA
5	Runout(RDL)	MAX,MIN,A1,A2
6	Runout(AXL)	MAX,MIN,A1,A2
7	Squareness(AXS)	ANG
8	Squareness(PLN)	ANG
9	Thickness-DV	MAX,MIN,A1,A2
10	Flatness	P,V,MLA,PC,DX,DY
11	FLTt	FLTp,FLTv,FLTq,PC,DX,DY
12	Parallelism	ANG
13	Parallel(Runout)	
14	Cylindricity	DX,DY,DL,DA
15	Simple Cylind.	DX,DY,DL,DA
16	Mean Cylind.	DX,DY,DL,DA

(3) Figure window

It displays the same figure as the one printed out through RA-10/120. (In case of A4 setting)

## 4.2 Print



Print


Press the [Print] button to print a “simple inspection certificate”.  
Regarding the contents of printing, refer to [4.4 Export].

## 4.3 Print preview



Press the [Preview] button to display the print preview of the “simple inspection certificate”. It is possible to print out after checking the print preview.

【Ex. excel 2010】




Regarding the contents of print preview, refer to [4.4 Export].

## 4.4 Export




Press the [Export] to create the “simple inspection certificate”. It is possible to save anywhere.

【Ex. excel 2010】



(1) The format of the “Simple inspection certificate” is as below.




- ① Figure window : The contents of [③, 3.1 Overall view] is displayed.  
(It does not display in the case of [NO figure].)
- ② Result list. : The contents of [② 3.1 Overall view] is displayed.
- ③ Condition list : The contents of [① 3.1 Overall view] is displayed.
- ④ Contents window : The contents set at [4.6. Comment settings].  
(Regarding measurement date, it indicates the date included in the measured date taken from PA-120.)

#### 4. RA-10/120 Method of USB Communication Usage

(2) This section explains regarding saving the “simple inspection certificate”.

Click [Yes] to save the simple inspection certificate.

The dialog of “Name and save” shows up. Name the file and Click [Save].



#### 4.5 Language setting



It is possible to set language of the screen or the “simple inspection certificate”.

Applicable languages are as below.

Japanese	TRAD. Chinese
English	SIMP. Chinese
German	Czech
French	Polish
Italian	Hungarian
Spanish	Turkish
Portuguese	Swedish
Korean	Dutch



\* This language setting does not match with the language of RA-10/120 settings.


## 4.6 Comment settings



It is possible to add “Comment” to the “simple inspection certificate”.

Addible items are as below.

Date Time	10/5/2012 12:35:00 PM
WorkName	BOWL
Operator	KEN
Comment	
Machine	RA-120
Comment	TEST



① WorkName :

If the WorkName is set on RA-10/120, it displays the WorkName.

It is possible to set the WorkName as you like if it is not set on RA-10/120 (the column is blank). In this case, it displays “WorkName”, but it is possible to set any text.

② Operator :

If the Operator is set on RA-10/120, it displays the Operator..

It is possible to set the Operator as you like if it is not set on RA-10/120 (the column is blank). In this case, it displays “Operator”, but it is possible to set any text.

③ Machine :

Regardless of RA-10/120 settings, it is possible to set as you like.


In this case, it displays “Machine”, but it is possible to set any text.

④ Comment :

Regardless of RA-10/120 settings, it is possible to set as you like.

In this case, it displays “Comment”, but it is possible to set any text.

### 4.7 Print settings




4.1.It is possible to print at the same time of reading.

Auto print : print at the same time of reading

Manual print : only reading

### 4.8 Paper selection




It is possible to select paper size at the operation of [4.2. Print], [4.3. Print Preview], [4.4. Export].

### 4.9 Figure



It is possible to read figure by checking [Figure]. If you don't check it, it does not display figure on the "simple inspection certificate".

### 4.10 Quit



Finish USB communication

---

MEMO

# 5

## RA-10/120 USB Communication Performance Environment

RA-10/120 USB Communication performance environment is as below.

OS	Windows XP-SP3/Vista/Windows7(32Bit/64bit)
Excel	Excel 2010
Display	Equal or more than 1024×768 dots, High color (equal or more than 16Bit)

### NOTE

- As for “over Windows Vista Business/Windws7”, please use as a controller.
- In the case that a security level of Excel is high, it does not work appropriately occasionally.
- The language displayed on the software is in the system font of the PC currently used. Even though it does not display appropriately (gibberish text) or all the text can not be displayed on the screen depending on the language occasionally, there are no problems with the performance.

- (1) Windows is a registered brand of Microsoft (U.S.A).
- (2) Excel is a registered brand of Microsoft (U.S.A).
- (3) Other company names or produt names mentioned on this manual are registerd brand of the company for each.

---

MEMO

# SERVICE NETWORK

\*As of February 2013

## Europe

### Mitutoyo Europe GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY  
TEL:49(2137)102-0 FAX:49(2137)102-351

## Germany

### Mitutoyo Deutschland GmbH

Borsigstrasse 8-10, 41469 Neuss, GERMANY  
TEL:49(2137)102-0 FAX:49(2137)86 85

### M3 Solution Center Hamburg

Tempowerkring 9 im HIT-Technologiepark 21079 Hamburg, GERMANY  
TEL:49(40)791894-0 FAX:49(40)791894-50

### M3 Solution Center Leonberg

Steinbeisstrasse 2, 71229 Leonberg, GERMANY  
TEL:49(7152)6080-0 FAX:49(7152)608060

### M3 Solution Center Berlin

Paradiesstrasse 208, 12526 Berlin, GERMANY  
TEL:49(30)2611 267 FAX:49(30)26 29 209

### M3 Solution Center Eisenach

im bte Eisenach, Heinrich-Ehrhardt-Platz, 99817 Eisenach, GERMANY  
TEL:49(3691)88909-0 FAX:49(3691)88909-9

### M3 Solution Center Ingolstadt

Ziegeleistrasse 66, 85055 Ingolstadt, GERMANY  
TEL:49 (841) 954920 FAX:49 (841) 9549250

## U.K.

### Mitutoyo (UK) Ltd.

Joule Road, West Point Business Park, Andover, Hampshire SP10 3UX, UNITED KINGDOM  
TEL:44(1264)353123 FAX:44(1264)354883

### M3 Solution Center Coventry

Unit6, Banner Park, Wickmans Drive, Coventry, Warwickshire CV4 9XA,  
UNITED KINGDOM  
TEL:44(2476)426300 FAX:44(2476)426339

### M3 Solution Center Halifax

Lowfields Business Park, Navigation Close, Elland, West Yorkshire HX5 9HB,  
UNITED KINGDOM  
TEL:44(1422)375566 FAX:44(1422)328025

### M3 Solution Center East Kilbride

The Baird Bulding, Rankine Avenue, Scottish Enterprise Technology Park, East  
Kilbride G75 0QF, UNITED KINGDOM  
TEL:44(1355)581170 FAX:44(1355)581171

## France

### Mitutoyo France

Paris Nord 2-123 rue de la Belle Etoile, BP 59267 ROISSY EN FRANCE 95957  
ROISSY CDG CEDEX, FRANCE  
TEL:33(1) 49 38 35 00 FAX:33(1) 48 63 27 70

### M3 Solution Center LYON

Parc Mail 523, cours du 36me millénaire, 69791 Saint-Priest, FRANCE  
TEL:33(1) 49 38 35 70 FAX:33(1) 49 38 35 79

### M3 Solution Center STRASBOURG

Parc de la porte Sud, Rue du pont du péage, 67118 Geispolsheim, FRANCE  
TEL:33(1) 49 38 35 80 FAX:33(1) 49 38 35 89

### M3 Solution Center CLUSES

SPACE Scionzier 480 Av. des Lacs, 74950 Scionzier, FRANCE  
TEL:33(1) 49 38 35 90 FAX:33(1) 49 38 35 99

### M3 Solution Center TOULOUSE

Aeroparc Saint-Martin ZAC de Saint Martin du Touch 12 rue de Caulet, 31300  
Toulouse, FRANCE  
TEL:33 (5) 82 95 25 21

## Italy

### MITUTOYO ITALIANA S.r.l.

CORSO Europa, 7 - 20020 Lainate (MI), ITALY  
TEL:39(02)935781 FAX:39(02)9373290-93578255

### M3 Solution Center VERONA

VIA A. Volta, 37062 Dosso Buono (VR), ITALY  
TEL:39(045)513012 FAX:39(045)8617241

### M3 Solution Center TORINO

VIA Brandizzo, 133/F - 10088 Volpiano (TO), ITALY  
TEL:39(011) 9123995 FAX:39(011) 9953202

### M3 Solution Center CHIETI

Contrada Santa Calagna - 66020 Rocca S. Giovanni (CH), ITALY  
TEL/FAX:39(0872)709217

## Netherlands

### Mitutoyo Nederland B.V.

Storkstraat 40, 3905 KX Veenendaal, THE NETHERLANDS  
TEL:31(0)318-534911 FAX:31(0)318-534811

### Mitutoyo Research Center Europe B.V.

De Rijn 18, 5684 PJ Best, THE NETHERLANDS  
TEL:31(0)499-320200 FAX:31(0)499-320299

## Belgium

### Mitutoyo Belgium N.V.

Hogenakkerhoek straat 8, 9150 Kruibeke, BELGIUM  
TEL:32(0)3-2540444 FAX:32(0)3-2540445

## Sweden

### Mitutoyo Scandinavia AB

Släntvägen 6, 194 54 Upplands Väsby, SWEDEN  
TEL:46(0)8 594 109 50 FAX:46(0)8 590 924 10

### M3 Solution Center Alingsas

Kristineholmsvägen 26, 441 39 Alingsas, SWEDEN  
TEL:46(0)8 594 109 50 FAX:46(0)322 63 31 62

### M3 Solution Center Värnamo

Storgatsbacken 9, 331 30 Värnamo, SWEDEN  
TEL:46(0)8 594 109 50 FAX:46(0)370 463 34

## Finland

### Mitutoyo Scandinavia AB Finnish Branch

Viherkitääjä 2A, FI-33960, Pirkkala, Finland  
TEL: +358 207 929 640

## Switzerland

### Mitutoyo Schweiz AG

Steinackerstrasse 35, 8902 Urdorf, SWITZERLAND  
TEL:41(0)447361150 FAX:41(0)447361151

## Poland

### Mitutoyo Polska Sp.z o.o.

ul.Minska 54-56, 54-610 Wroclaw, POLAND  
TEL:48(71)354 83 50 FAX:48(71)354 83 55

## Czech Republic

### Mitutoyo Ceako, s.r.o.

Dubská 1626, 415 01 Teplice, CZECH REP  
TEL:420-417-579-866 FAX:420-417-579-867

## Hungary

### Mitutoyo Hungária Kft.

Németvölgyi út 97, H-1124 Budapest, HUNGARY  
TEL:36(1)2141447 FAX:36(1)2141448

## Romania

### Mitutoyo Romania SRL

1A, Drumul Garii Odai Street, Ground Floor, Room G03,  
075100 OTOPENI-ILFOV, ROMANIA  
TEL:40(0)311012088 FAX:40(0)311012089

## Russian Federation

### Mitutoyo RUS LLC

13 Sharikopodshipnikovskaya, bld.2, 115088 Moscow, RUSSIAN FEDERATION  
TEL:(7)495 7450 752 FAX:(7)495 745 0752

## Singapore

### Mitutoyo Asia Pacific Pte. Ltd.

24 Kallang Avenue, Mitutoyo Building, SINGAPORE 339415  
TEL:(65)62942211 FAX:(65)62996666

## Malaysia

### Mitutoyo (Malaysia) Sdn. Bhd.

Kuala Lumpur Head Office / M3 Solution Center  
Mah Sing Intergrated Industrial Park, 4, Jalan Utarid U5/14, Section U5, 40150  
Shah Alam, Selangor, MALAYSIA  
TEL:(60)3-78459318 FAX:(60)3-78459346

### Penang Branch office / M3 Solution Center

No.30, Persiaran Mahsuri 1/2, Sunway Tunas, 11900 Bayan Lepas, Penang,  
MALAYSIA  
TEL:(60)4-6411998 FAX:(60)4-6412998

### Johor Branch office / M3 Solution Center

No. 70, Jalan Molek 1/28, Taman Molek, 81100 Johor Bahru, Johor, MALAYSIA  
TEL:(60)7-3521626 FAX:(60)7-3521628

## Indonesia

### PT. Mitutoyo Indonesia

### Head Office / M3 Solution Center

Ruko Mall Bekasi Fajar Blok A6&A7 MM2100 Industrial Town, Cikarang Barat,  
Bekasi 17520, INDONESIA  
TEL:(62)21-8980841 FAX:(62)21-8980842

## Thailand

### Mitutoyo(Thailand)Co., Ltd.

### Bangkok Head Office / M3 Solution Center

No. 76/3-5, Chaengwattana Road, Anusaowaree, Bangkaen, Bangkok 10220,  
THAILAND  
TEL:(66)2-521-6130 FAX:(66)2-521-6136

### Cholburi Branch / M3 Solution Center

No.7/1, Moo 3, Tambon Bowin, Amphur Sriracha, Cholburi 20230, THAILAND  
TEL:(66)3-834-5783 FAX:(66)3-834-5788

### Amata Nakorn Branch / M3 Solution Center

No. 700/199, Moo 1, Tambon Ban Kao, Amphur Phan Thong, Cholburi 20160,  
THAILAND  
TEL:(66)3-846-8976 FAX:(66)3-846-8978

## Vietnam

### Mitutoyo Vietnam Co., Ltd

### Hanoi Head Office / M3 Solution Center

No.34-TT4, My Dinh-Me Tri Urban Zone, My Dinh Commune, Tu Liem District,  
Hanoi, VIETNAM  
TEL:(84)4-3768-8963 FAX:(84)4-3768-8960

### Ho Chi Minh City Branch Office / M3 Solution Center

31 Phan Xich Long Street, Ward 2, Phu Nhuan District, Ho Chi Minh City,  
VIETNAM  
TEL:(84)8-3517-4561 FAX:(84)8-3517-4582

## India

### Mitutoyo South Asia Pvt. Ltd.

### Head Office / M3 Solution Center

C-122, Okhla Industrial Area, Phase-I, New Delhi-110 020, INDIA  
TEL:91(11)2637-2090 FAX:91(11)2637-2636

### Mumbai Region Head office

303, Sentinel Hiranyandani Business Park Powai, Mumbai-400 076, INDIA  
TEL:91(22)2570-0684, 837, 839 FAX:91(22)2570-0685

### Pune Office / M3 Solution Center

G2/G3, Pride Kumar Senate, F.P. No. 402 Off. Senapati Bapat Road, Pune-411 016,  
INDIA  
TEL:91(20)6603-3643, 45, 46 FAX:91(20)6603-3644

### Vadodara office

S-1&S-2, Olive Complex, Nr. Haveli, Nizampura, Vadodara-390 002, INDIA

TEL: (91) 265-2750781 FAX: (91) 265-2750782

# SERVICE NETWORK

\*As of February 2013

## Bengaluru Region Head office / M3 Solution Center

No. 5, 100 Ft. Road, 17th Main, Kiramangala, 4th Block, Bengaluru-560 034, INDIA

TEL:91(80)2563-0946, 47, 48 FAX:91(80)2563-0949

## Chennai Office / M3 Solution Center

No. 624, Anna Salai Teynampet, Chennai-600 018, INDIA

TEL:91(44)2432-8823, 24 FAX:91(44)2432-8825

## Kolkata Office

Unit No. 1208, Om Tower, 32,J.L.Nehru Road, Kolkata-700 071

Tel: (91) 33-22267088/40060635 Fax: (91) 33-22266817

## Taiwan

### Mitutoyo Taiwan Co., Ltd.

4F., No.71, Zhouzi St., Neihu Dist., Taipei City 114, TAIWAN (R.O.C.)

TEL:886(2)8752-3266 FAX:886(2)8752-3267

### Taichung Branch

16F.-3, No.6, Ln.256, Sec.2, Xitun Rd., Xitun Dist., Taichung City 407, TAIWAN (R.O.C.)

TEL:886(4)2707-1766 FAX:886(4)2451-8727

### Kaohsiung Branch

13F.-3, No.31, Haibian Rd., Lingya Dist., Kaohsiung City 802, TAIWAN (R.O.C.)

TEL:886(7)334-6168 FAX:886(7)334-6160

### M3 Solution Center Taipei

4F., No.71, Zhouzi St., Neihu Dist., Taipei City 114, TAIWAN (R.O.C.)

TEL:886(2)8752-3266 FAX:886(2)8752-3267

### M3 Solution Center Tainan

Rm.309, No.31, Gongye 2nd Rd., Annan Dist., Tainan City 709, TAIWAN (R.O.C.)

TEL:886(6)384-1577 FAX:886(6)384-1576

## South Korea

### Mitutoyo Korea Corporation

#### Head Office / M3 Solution Center

(Geumjeong high view Build), 6F, 153-8, Ls-ro, Gunpo-si, Gyeonggi-do, 435-040, KOREA

TEL:82(31)361-4200 FAX:82(31)361-4201/4202

#### Busan Office / M3 Solution Center

Donghun Build, 1F, 559-13 Gwaebo-p-Dong, Sasang-Gu, Busan, 617-809, KOREA

TEL:82(51)324-0103 FAX:82(51)324-0104

#### Daegu Office / M3 Solution Center

371-12, Hosan-Dong, Dalseo-Gu, Daegu, 704-230, KOREA

TEL:82(53)593-5602 FAX:82(53)593-5603

## China

### Mitutoyo Measuring Instruments (Shanghai) Co., Ltd.

12F, Nextage Business Center, No.1111 Pudong South Road, Pudong New District, Shanghai 200120, CHINA

TEL:86(21)5836-0718 FAX:86(21)5836-0717

### Suzhou Office / M3 Solution Center China (Suzhou)

No. 46 Baiyu Road, Suzhou 215021, CHINA

TEL:86(512)6522-1790 FAX:86(512)6251-3420

### Wuhan Office

RM. 1206B Wuhan World Trade Tower, No. 686, Jiefang Ave, Jianghan District, Wuhan 430032, CHINA

TEL:86(27)8544-8631 FAX:86(27)8544-8227

### Chengdu Office

RM. D 20/F, No.58 Beixin Road, Jinjiang District, Chengdu, Sichuan 610016, CHINA

TEL:86(28)8671-8936 FAX:86(28)8671-9086

### Hangzhou Office

RM. 902, Taifu Plaza No.1 Tonghui (M) Road, Xiaoshan District, Hangzhou 312000, CHINA

TEL:86(571)8288-0319 FAX:86(571)8288-0320

### Tianjin Office / M3 Solution Center Tianjin

No.16 Heimucheng-Road, Hexi-District, Tianjin 300210, CHINA

TEL:86(22)8558-1221 FAX:86(22)8558-1234

### Changchun Office

RM.1801, Kaifa Dasha, No. 5188 Ziyu Avenue, Changchun 130013, CHINA

TEL:86(431)8461-2510 FAX:86(431)8464-4411

### Qingdao Office / M3 Solution Center Qingdao

No.135-10, Fuzhou North Road, Shibei District, Qingdao City, Shandong 266034, CHINA

TEL:86(532)8066-8887 FAX:86(532)8066-8890

### Xian Office

RM. 805, Xi'an International Trade Center, No. 196 Xiaozhai East Road, Xi'an, 710061, CHINA

TEL:86(29)8538-1380 FAX:86(29)8538-1381

### Dalian Office / M3 Solution Center Dalian

RM. 1008,YOMA IFC,No.128 Jin ma Road,Economic Development Zone, Dalian 116600, CHINA

TEL:86(411)8718 1212 FAX:86(411)8754-7587

### Mitutoyo Leepot Metrology (Hong Kong) Limited

1/F., Block 1, Golden Dragon Industrial Center, 152-160 Tai Lin Pai Road, Kwai Chung, N.T., HONG KONG

TEL:86852)2427-7991 FAX:86(852)2418-4610

### Mitutoyo Leepot Metrology (Dongguan) Limited / M3 Solution Center Dongguan

No.26, Guan Chang Road, Chong Tou Zone, Chang An Town, Dong Guan, 523855 CHINA

TEL:86(769)8541 7715 FAX:86(769)-8541 7745

### Mitutoyo Measuring Instruments (Suzhou) Co., Ltd.

No. 46 Baiyu Road, Suzhou 215021, CHINA

TEL:86(512)6252-2660 FAX:86(512)6252-2580

## U.S.A.

### Mitutoyo America Corporation

965 Corporate Blvd., Aurora, IL 60502, U.S.A.

TEL:1-(630)820-9666 Toll Free No. 1-888-648-8869 FAX:1-(630)820-2614

## M3 Solution Center-Illinois

945 Corporate Blvd., Aurora, IL 60502, U.S.A.

### M3 Solution Center-Ohio

6220 Hi-Tek Ct., Mason, OH 45040, U.S.A.

TEL:1-(513)754-0709 FAX:1-(513)754-0718

### M3 Solution Center-Michigan

44768 Helm Street, Plymouth, MI 48170, U.S.A.

TEL:1-(734)459-2810 FAX:1-(734)459-0455

### M3 Solution Center-California

16925 E. Gale Ave., City of Industry, CA 91745, U.S.A.

TEL:1-(626)961-9661 FAX:1-(626)333-8019

### M3 Solution Center-Massachusetts

1 Park Dr., Suite 11, Westford, MA 01886, U.S.A.

TEL:1-(978)692-8765 FAX:1-(978)692-9729

### M3 Solution Center-North Carolina

11515 Vanstory Dr., Suite 150, Huntersville, NC 28078, U.S.A.

TEL:1-(704)875-8332 FAX:1-(704)875-9273

### M3 Solution Center-Alabama

2100 Riverchase Center Suite 106 Hoover, AL 35244, U.S.A.

TEL:1-(205)-988-3705 FAX:1-(205)-988-3423

### Micro Encoder, Inc.

11533 NE 118th St., bldg. M, Kirkland, WA 98034, U.S.A.

TEL:1-(425)821-3906 FAX:1-(425)821-3228

## Canada

### Mitutoyo Canada Inc.

2121 Meadowvale Blvd., Mississauga, Ont. L5N 5N1., CANADA

TEL:1-(905)821-1261 FAX:1-(905)821-4968

## Montreal Office

7075 Place Robert-Joncas Suite 129, Montreal, Quebec H4M 2Z2, CANADA

TEL:1-(514)337-5994 FAX:1-(514)337-4498

## Brazil

### Mitutoyo Sul Americana Ltda.

AV. Joao Carlos da Silva Borges, 1240 - CEP 04726-002 - Santo Amaro -

São Paulo - SP, BRASIL

TEL:55(11)5643-0000 FAX:55(11)5641-3722

### Regional Office

Belo Horizonte - MG

TEL:55(31)3531-5511 FAX:55(31)3594-4482

### Rio Grande do Sul / PR, SC

TEL/FAX:55(51)3342-1498 TEL:55(51)3337-0206

### Rio de Janeiro - RJ

TEL:55(21)3333-4899 TEL/FAX:55(21)2401-9958

### Santa Barbara D'Oeste - SP

TEL:55(19)3455-2062 FAX:55(19)3454-6103

### Norte, Nordeste, Centro Oeste

TEL:55(11)5643-0060 FAX:55(11)5641-9029

### Escrivtoria BA / SE

TEL/FAX:55(11)3326-5232

### Factory(Suzano)

Rodovia Indio Tibirica 1555, BAIRRO RAFFO, CEP 08620-000 SUZANO-SP, BRASIL

TEL:55(11)4746-5858 FAX:55(11)4746-5936

## Argentina

### Mitutoyo Sul Americana Ltda.

#### Argentina Branch

Av. Mitre 891/899 CP(B1603CQD) Vicente Lopez Buenos Aires, ARGENTINA

TEL:54(11)4730-1433 FAX:54(11)4730-1411

### Sucursal Cordoba

Av. Amadeo Sabattini, 1296, esq. Madrid Bº Crisol Sur - CP 5000, Cordoba, ARGENTINA

TEL/FAX:54 (351) 456-6251

## Mexico

### Mitutoyo Mexicana, S. A. de C. V

Prolongación Industria Eléctrica No. 15 Parque Industrial Naucalpan

Naucalpan de Juárez, Estado de México C.P. 53370, MÉXICO

TEL: 52 (01-55) 5312-5612, FAX: 52 (01-55) 5312-3380

### Monterrey Office / M3 Solution Center

Av. Morones Prieto No. 914. Ote., Local 105 - Plaza Malz Col. La Huerta, C.P. 67140 Guadalupe, N.L., México

TEL: 52 (01-81) 8398-8228, 8398-8227 and 8398-8244 FAX: 52 (01-81) 8398-8226

### Tijuana Office / M3 Solution Center

Av. 2o. eje Oriente-Poniente No. 19075 Int. 18 Col. Cd. Industrial Nueva Tijuana C.P. 22500 Tijuana, B. C., México

TEL: 52 (01-664) 624-3644 and 624-3645 FAX: 52 (01-664) 647-5024

### Querétaro Office / M3 Solution Center

Acceso "C" No. 107 Col. Parque Industrial Jurica C.P. 76100 Querétaro, Qro., México

TEL: 52 (01-442) 340-8018, 340-8019 and 340-8020 FAX: 52 (01-442) 340-8017

### Irapuato Office / M3 Solution Center

Av. Héroes de Nacozari No. 1655, local A-14 esq. con Boulevard Villas de Irapuato "Plaza Delta" Col. San Miguelito, C.P. 36557 Irapuato, Gto., México



# **Mitutoyo Corporation**

20-1, Sakado 1-Chome, Takatsu-ku, Kawasaki-shi, Kanagawa 213-8533, Japan

Tel: +81 (0)44 813-8230      Fax: +81 (0)44 813-8231

Home page: <http://www.mitutoyo.co.jp/global.html>